

Spill Cart



Poly-Spillcart lets you move and store batteries around your plant, eliminating the risk of acid leak.



Built-in tool tray keeps tools and other small objects clean and handy.



Large internal sump hold incidental spills.



Rear casters pivot 360° to let you move around freely; each with wheel brakes for securing position.



Dual drain plugs let you empty sump easily from below .

Specifications	Spill Cart	Spill Cart ATC (All-Terrain Casters)
Product Number	SC-1000	SC-H000
Dimensions w/Handle	66.5"L x 29"W x 43.25"H 169 cm x 74 cm x 110 cm	66.5"L x 29"W x 43.25"H 169 cm x 74 cm x 110 cm
Dimensions w/o Handle	66.5"L x 29"W x 16"H 169 cm x 74 cm x 41 cm	66.5"L x 29"W x 16"H 169 cm x 74 cm x 41 cm
Weight	119 lbs. with grate / 53.55 kg	121 lbs. / 54.45 kg
Load Bearing Capacity UDL	500 lbs. / 225 kg.	500 lbs. / 225 kg.
Sump Capacity	57 gal./ 216 L. (both sumps)	57 gal./ 216 L. (both sumps)
Regulations	EPA 40 CFR 264.175	EPA 40 CFR 264.175